



## Application Instructions for RockSolid® Natural Look Concrete Sealer

**SURFACE PREPARATION:** Proper surface preparation is critical to achieve best results. Allow newly poured concrete to cure for a minimum of 28 days. Sweep away all loose dirt and debris, and remove any vegetation. If necessary, use a wire brush or sander to remove any loose or unsound concrete or masonry. Remove any efflorescence with a **RockSolid® Efflorescence Remover** (sold separately). Clean entire surface, including any oil or grease spots, with **RockSolid® Heavy Duty Cleaner** (sold separately). Scrub surface with a stiff bristle brush or broom. Rinse thoroughly with fresh water, preferably with a power washer. Repeat as necessary to completely clean and rinse. Allow to dry to the touch (typically 4 to 6 hours) before applying **RockSolid® Natural Look Concrete Sealer**.

**COVERAGE:** Each gallon covers 200 to 400 square feet (single coat), depending on the porosity of the surface. Porous surfaces may require additional coats.

**APPLICATION:** **RockSolid® Natural Look Concrete Sealer** is ready to use. Do not thin. Use only when air (ambient) temperature is 50-90°F (10-32°C) and relative humidity is below 85% during day and night. Do not apply in direct sunlight. Do not apply if rain is expected within 24 hours. Use in well-ventilated areas.

- Mask adjacent surfaces to apply spray application up to all edges. Protect delicate foliage from overspray. Apply using a standard pump sprayer with an adjustable spray tip.\*
  - Stir container to mix product. Fill pump sprayer with product, then fully pressurize the sprayer. Set sprayer tip to a medium-fine mist and spray 10"-12" from the surface. Do not pour product on surface or allow product to puddle.
  - Start and stop the sprayer just off the work area to prevent drips. For larger areas, work in 6' x 6' sections at a time before moving to the next section.
  - Apply the product evenly, using a circular or oval pattern to saturate the surface. Backroll any puddles with a 3/8" to 1/2" nap roller.
  - For additional protection on heavy traffic areas or for more porous surfaces, wait 4 to 6 hours to recoat.
  - Occasional touch-up or recoat may be necessary for areas exposed to heavy foot or vehicle traffic.
- \*Alternate application method is to apply with a 3/8" to 1/2" nap roller from a paint tray.

**DRY TIME:** Wait a minimum of 4 to 6 hours for light foot traffic. Wait 24 to 48 hours before returning heavy items, furniture, and vehicles. Dry time is based on 70°F & 50% relative humidity.

**CLEAN UP:** Soap and water.