



RockSolid® Penetrating Concrete Sealer Application Instructions

SURFACE PREPARATION: Proper surface preparation is critical to achieve best results. Allow newly poured concrete to cure for a minimum of 28 days. Sweep away all loose dirt and debris, and remove any vegetation. If necessary, use a wire brush or sander to remove any loose or unsound concrete or masonry. Remove any efflorescence with **ROCKSOLID® Efflorescence Remover** (sold separately). Clean entire surface, including any oil or grease spots, with **ROCKSOLID® Heavy Duty Cleaner** (sold separately). Scrub surface with a stiff bristle brush or broom. Rinse thoroughly with fresh water, preferably with a power washer. Repeat as necessary to completely clean and rinse. Allow to dry to the touch (typically 4 to 6 hours) before applying product.

COVERAGE: Each gallon covers approximately 250 square feet (single coat). Coverage will vary depending on the porosity of the surface. Porous surfaces may require multiple coats.

APPLICATION: **ROCKSOLID® Penetrating Concrete Sealer** is ready to use. Do not thin. Use only when air (ambient) temperature is 50-90°F (10-32°C) and relative humidity is below 85% during day and night. Do not apply in direct sunlight. Do not apply if rain is expected within 24 hours. Use in well-ventilated areas. Avoid applying late in the day when temperatures are falling as the formation of dew can interfere with proper sealing.

- Mask adjacent surfaces to allow spray application up to all edges. Protect delicate foliage from overspray. Apply using a standard pump sprayer with an adjustable spray tip, or apply using a standard 3/8" nap roller. Choose the best applicator for the size of the project and texture of the concrete. Do not pour product on surface or allow product to puddle.
- Stir container to mix product. Fill pump sprayer with product, then fully pressurize the sprayer. Set sprayer tip to a medium-fine mist and spray 10"-12" from the surface.
- Start and stop the sprayer just off of the work area to prevent drips. For larger areas, work in 6' x 6' sections at a time before moving to the next section.
- Apply product evenly, using a circular or oval pattern to saturate the surface. Do not allow sealer to puddle. Backroll any puddles using a 3/8" nap roller.

DRY TIME: Wait a minimum of 4 to 6 hours for light foot traffic. Wait 24 to 48 hours before returning heavy items, furniture, and vehicles. Dry time is based on 70°F & 50% relative humidity.

CLEAN UP: Soap and water