

Dräger PARAT® Soft Pack

Donning Poster



Dräger PARAT® Soft Pack



Pull the yellow flap downwards. The security seal breaks automatically.



Open the Soft Pack completely so that the front filter sealing plug is removed.



Remove the hood from the Soft Pack.



The second filter sealing plug is detached from the hood.



Widen the neck seal and pull the hood over your head. Ensure that nose and chin sit comfortably in the half mask and all hair is tucked into the hood.



Check the fit of the half mask by closing the front filter opening with the palm of your hand. Breathe in.



If negative pressure is not generated readjust the half mask to ensure a close fit over nose and mouth.



Ready for escape.

Always read and understand the instructions for use of the Dräger PARAT® escape device prior to use!